

winco®

PORTABLE SINGLE-RANGE GAS STOVE

Operating Instruction Manual



PGS-1K

Model	Input Rating	Power (g/H)	Fuel	Thermal Flux	Dimensions		
					Width	Depth	Height
PGS-1K	9500 BTU /h	155 g / H	Butane Gas	2.5 KW	13" 330mm	11" 280mm	4.33" 110mm

BEFORE OPERATING ANY EQUIPMENT, READ AND FAMILIARIZE YOURSELF WITH THESE USE AND SAFETY INSTRUCTIONS

*Congratulations on your purchase of this WINCO commercial gas range. WINCO takes pride in the quality of its products. When used as intended and with proper care and maintenance, you will experience years of reliable operation from this equipment. To ensure best results, it is important that you read and follow the instructions in this manual carefully. **It's important to save these instructions for future reference.***

Portable Single-Range Gas Stove

Important For Future Reference

Please complete this information and retain this manual for the life of the product. For Warranty Service and/or parts, this information is required. Please see page 8 for more information on your Warranty and how to register.

PGS-1K

Model Number

Serial Number

Date Purchased



WARNING: IMPROPER INSTALLATION, ADJUSTMENT, ALTERATION, SERVICE OR MAINTENANCE CAN CAUSE PROPERTY DAMAGE, INJURY, OR DEATH. READ THE INSTALLATION, OPERATION, AND MAINTENANCE INSTRUCTIONS THOROUGHLY BEFORE INSTALLING OR SERVICING THIS EQUIPMENT.

AVERTISSEMENT: TOUTE INSTALLATION, RÉGLAGE, MODIFICATION, RÉPARATION OU ENTRETIEN INCORRECT PEUT OCCASIONNER DES DOMMAGES MATÉRIELS, DES BLESSURES GRAVES OU LA MORT. LIRE LES INTRUCTIONS D'INSTALLATION, D'UTILISATION ET D'ENTRETIEN ATTENTIVEMENT AVANT D'INSTALLER OU DE RÉPARER CET APPAREIL.



CAUTION: THESE MODELS ARE DESIGNED, BUILT, AND SOLD FOR COMMERCIAL USE ONLY. IF THESE MODELS ARE POSITIONED SO THE GENERAL PUBLIC CAN USE THE EQUIPMENT, MAKE SURE THAT CAUTION SIGNS, WARNINGS, AND OPERATING INSTRUCTIONS ARE CLEARLY POSTED NEAR EACH UNIT SO THAT ANYONE USING THE EQUIPMENT WILL USE IT CORRECTLY AND NOT INJURE THEMSELVES OR HARM THE EQUIPMENT.

ATTENTION: CES MODÈLES SONT CONÇUS, FABRIQUÉS, ET VENDUS POUR UN USAGE COMMERCIAL SEULEMENT. SI CES MODÈLES SONT PLACÉS POUR QUE LE GRAND PUBLIC PUISSE LES UTILISER, ASSUREZ-VOUS QUE LES CONSIGNES D'ATTENTION, D'AVERTISSEMENT, ET LES INSTRUCTIONS D'UTILISATION SOIENT CLAIEMENT AFFICHÉES PRÈS DE CHAQUE UNITÉ DE SORTE QUE N'IMPORTE QUEL UTILISATEUR DE L'APPAREIL L'EMPLOIE CORRECTEMENT ET NE SE BLESSE PAS OU N'ENDOMMAGE PAS L'APPAREIL.



WARNING: A FACTORY AUTHORIZED SERVICE PROVIDER SHOULD HANDLE ALL MAINTENANCE AND REPAIR. FOLLOW THE SERVICE SET-UP ARRANGEMENTS BEFORE ATTEMPTING ANY REPAIR OR MAINTENANCE.

AVERTISSEMENT: UN TECHNICIEN AUTORISÉ PAR L'USINE DEVRA EFFECTUER TOUT L'ENTRETIEN ET LES RÉPARATIONS. AVANT DE FAIRE TOUT ENTRETIEN OU RÉPARATION, VEUILLEZ CONTACTER WINCO.



Introduction

Congratulations on the purchase of your WINCO machine. Please take the time to carefully read through this manual to ensure the machine is operated and maintained properly, to ensure the best possible performance from this product for many years.

WINCO will not accept liability if:

- The instructions in this manual have not been followed correctly.
- Non-authorized personnel have tampered with the machine.
- Non-original spare parts are used.
- The machine has not been handled and cleaned correctly.
- There is any use damage to the unit.

Portable Single-Range Gas Stove

Table of Contents

Specifications	1
Warnings	2
Introduction	2
Table of Contents	3
Packaging	3
Important Safeguards.....	4
Cleaning, Care & Maintenance	4
Part Identification.....	5
Operation	6
Safety	7
Service & Repair	7
Troubleshooting	7
Limited Warranty	8

Package Contents

All units come with an Operating Instruction Manual and the following:

- PGS-1K Portable Single-Range Gas Stove

WINCO prides itself on quality and service, ensuring that at the time of packing, all products are supplied fully functional and free of damage. Should you find any damage as result of freight, please contact your WINCO dealer immediately.

Function and Purpose

This unit is intended to be used for cooking food in commercial food-service operations only. It is not intended for household, industrial or laboratory use.

NOTE

Please remember that this manual and the warning labels do not replace the need to be alert, to properly train and supervise operators, and to use common sense when using this equipment.

Unpacking the Equipment

DISPOSE OF ALL PACKAGING MATERIALS IN AN ENVIRONMENTALLY RESPONSIBLE MANNER.

1. Remove all packing materials and tape, as well as any protective plastic and cardboard, from the unit.
2. Clean any glue residue left over from the plastic or tape.
3. Place the unit in the desired position and height.

SAVE THE ORIGINAL BOX AND PACKAGING FOR USE IN PACKAGING AND SHIPPING THE EQUIPMENT IF SERVICES ARE NEEDED.

Important Safeguards

To ensure safe installation and operation, please carefully read and understand the following statements.

Unless the operator is adequately trained and supervised there is a possibility of serious injury. Owners of this equipment bear the responsibility to make certain that this equipment is used properly and safely, and to strictly follow all of the instructions contained in this manual and the requirements of local, state or federal law.

Owners should not permit anyone to touch this equipment unless they are over 18 years old, are adequately trained and supervised, and have read and understood this manual.

Owners should also ensure that no customers, visitors or other unauthorized personnel come in contact with this equipment. It is the responsibility of the owner and the operator to remain alert to any hazards posed by the function of this equipment.

If there is ever uncertainty about a particular task or the proper method of operating this equipment, ask an experienced supervisor.

Warnings

This manual contains a number of precautions to follow to promote safety while using this equipment.

FOR YOUR SAFETY

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

WARNING

Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death. Read this installation, operating and maintenance instructions thoroughly before installing or servicing this equipment.

TO PURCHASER

Contact your local gas supplier and ask instructions in the event the user smells gas. This information should be posted in a prominent location.

Cleaning, Care, Maintenance & Storage

Before using this equipment it must be cleaned and dried thoroughly. Clean all surfaces before use. Failure to clean surfaces before using the unit could cause food contamination.

Turn off and remove the gas canister from the unit and allow all surfaces to cool prior to cleaning and storing. Wipe with a damp cloth with cleanser, dry with a dry cloth.

Avoid using harsh or abrasive chemicals, metal tools or scouring agents as they may cause damage to the appliance or scratch the surfaces.


Never immerse the appliance in water.

Store the gas canister separately from the appliance and it should be kept in a cool, dry place when not in use.

NOTE:

Proper cleaning instructions must be followed; otherwise, operation of the unit may be seriously impaired. Do not wash parts in an automatic dishwasher.

Keep the appliance and gas canister away from children.

 HOT	WARNING ▲ AVERTISSEMENT	
	USE CAUTION WHEN TOUCHING THE UNIT.	Ne touchez pas le liquide chaud ou les surfaces de chauffage lorsque l'appareil chauffe ou en fonctionnement.

ESURE DE SECURITE

Ne pas entreposer ni utiliser d'essence ni autres vapeurs ou liquides inflammables a proximite de cet appareil ou de tout autre appareil!

AVERTISSEMENT

L'installation, le réglage, la modification, la réparation ou l'entretien incorrect de cet appareil peut causer des dommages matériels, des blessures ou la mort. Lire attentivement les instructions d'installation, de fonctionnement et d'entretien avant de procéder a son installation ou entretien.

À L'ACHETEUR


Communiquez avec votre distributeur de gaz et informez vous quant aux procédés a suivre si vous détectez une odeur de gaz. Cette information doit être affichée a un endroit facile d'accès et très visible.

Specifications

TYPE	Portable Single Range Gas Stove
MODEL	PGS-1K
WEIGHT	3.1 LBS
FUEL	Direct Pressure Butane Gas
GAS CONSUMPTION	155 g/hr
SAFETY DEVICE	Automatic Gas Shut-Off
HEAT OUTPUT RATING	9,500 BTU/hr

Part Identification

1. Brass Burner
2. Drip-pan
3. Body
4. Electronic Ceramic Needle
5. Pressure Sensor-Lock Lever
6. Temperature Control Dial
7. Auto Gas Shut-off Safety Device
8. Valve
9. Side Lid to Canister Compartment



Warning

Improper installation, adjustment, alteration, service, or maintenance can cause property damage, injury, or death. Read the installation, operation, and maintenance instructions thoroughly before installing or servicing this equipment.

IF YOU SMELL GAS: DO NOT ATTEMPT TO LIGHT THIS APPLIANCE AND REMOVE GAS CANISTER.

DANGER : CARBON MONOXIDE HAZARD

This appliance can produce carbon monoxide which is a colorless and odorless, potentially deadly gas. DO NOT Operate this appliance in an enclosed space or poorly ventilated space.

Caution Before Using Appliance

1. Read All instructions carefully
2. Inspect the product carefully upon unpacking. Should any part of the gas line or gas can be damaged, please notify the vendor and replace before use. Do not operate with damaged components. A factory authorized service provider should handle all maintenance and repair.
3. Do not touch hot surfaces, particularly ones marked "CAUTION: HOT." ALWAYS use caution when moving or operating the unit if its containers are holding hot liquid.
4. To protect against fire, do not place unit on combustible surface, and do not place flammable materials close to the burner.
5. Do not attempt to disassemble the gas stove; this will void the warranty.
6. Always unlatch the gas can when not in use and turn gas dial to off.
7. Remove gas can and allow to cool before cleaning.
8. When using the product indoors, provide proper ventilation to avoid Carbon Monoxide build up.
9. Do not heat empty containers on this unit.
10. Place the unit on a flat, stable surface. Do not place in, on, or near a hot burner, stove, oven, or any surface that can reach exceedingly hot temperatures.
11. Individuals unfamiliar with or unqualified to operate this machine, such as children, should not operate it without close and proper supervision.
12. Proper cleaning and care of the unit are necessary for the longevity and durability of the machine. Should proper procedures not be undertaken, it may void the warranty.
13. Improper use, handling, or adherence to these instructions or common sense may result in scalding or other injury.
14. When in use, the unit shall have a clearance of 8 inches from any side, and at least 5 feet from the top to any ceiling or covering.
15. Pots/pans shall be a minimum of 6 inches in diameter to be used on this unit.
16. For use with butane gas canisters, Types 2P or 2Q, which have been approved by the D.O.T.
17. Butane canisters are not reusable. Do Not try to refill them. Read the gas canisters caution labels before use.

Operation

1. Prior to first use, carefully unpack the gas stove and inspect it for damage.
2. Place on a level surface away from any other heated surfaces.
3. Flip the burner drip pan so the legs will support a pot/pan above the burner.
4. Open the gas compartment lid and place a butane can with the notch of the upper rim facing up. This notch will fit into the spring loaded latch to keep it in place.
5. Press the lock lever down until it locks in place. If the lock lever will not press down, the gas canister is either installed wrong or the gas dial is not in the OFF position.
6. If you smell gas or hear leaking gas, do not attempt to light the stove and remove the gas can.
7. Turn the gas dial switch to max and beyond until the dial 'clicks' to activate the electric igniter. If the igniter does not light the gas after several attempts, the igniter may be broken or the gas is empty. Turn off immediately to avoid the possibility of releasing excess gas.
8. Ensure to turn the gas dial to "OFF" and the lock lever is in the upward 'Release' position when the unit is not in use.

Safety

A WINCO Approved Service Technician should carry out repairs if necessary. Do not remove any components or service panels on this product.

If the power cord is damaged, it must be replaced by a WINCO Approved Service Technician in order to avoid a hazard.

Service and Repair

There are no user serviceable parts within this appliance. To avoid serious injury or damage, **NEVER** attempt to repair the unit yourself.

To initiate warranty service contact: support@wincous.com or call: 973-295-3899

DO NOT send unit to WINCO without first contacting our customer service department.

See "Limited Warranty" section on page 8 for details.

Troubleshooting

If your WINCO Portable Gas Stove does not operate, please check the following prior to placing a service call.

PROBLEM	POSSIBLE CAUSE	RECOMMENDED SOLUTION
The lock lever won't push down to the LOCK position	The gas dial is not in the off position	Turn the dial to the off position
	Drip pan has not been flipped over	Flip the drip pan over
	The gas canister is incorrect size	Only 8oz. butane cans can be used
	The gas canister is installed incorrectly	The gas can has a small cut along the rim that needs to be facing upward to align with a spring clip
The gas is leaking after locking (sound or smell). Wiping soapy water on the suspected area(s) will cause bubbles and help determine where the gas is escaping	The gas can is damaged	Replace gas can
	The seal or gas line is damaged	Contact your retailer
	The gas has been turned on	Turn gas dial to the OFF position until ready for use. DO NOT try starting the gas burner if you can smell or hear gas escaping. Remove butane canister and ventilate the area. Evacuate the immediate area and call for professional help.
The burner is not lighting all the way around	The burner may have debris in it	After the unit has been turned off and cooled, try using a toothpick to remove any debris from the burner holes.
Fire looks low or weak	Gas is low or almost empty	Change gas canister
	Debris is blocking the burner or nozzles, or the nozzle is not aligned.	After the unit has been turned off and cooled, try cleaning the burner and nozzle. The nozzle can be found at the copper tube leading to the bottom of the burner.
The electric igniter is not working	Debris could be blocking the igniter	Try cleaning the igniter pin next to the burner.
The flame is too weak	The igniter has disconnected or is broken	The igniter may have moved and is no longer sparking the burner. If possible, place in the correct position. Contact your retailer if it has broken.

Limited Warranty

WINCO warrants to the original purchaser of new equipment that said equipment, when installed in accordance with our instructions within North America and subjected to normal use, is free from defects in material or workmanship for a period of 1 year. The labor warranty is one year from original installation or 18 months from actual factory shipment date, whichever date occurs first.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, WHETHER EXPRESSED OR IMPLIED. WINCO EXPRESSLY DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR EXPRESSED OR IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

WINCO'S OBLIGATION AND LIABILITY UNDER THIS WARRANTY IS EXPRESSLY LIMITED TO REPAIRING AND REPLACING EQUIPMENT THAT PROVES TO BE DEFECTIVE IN MATERIAL OR WORKMANSHIP WITHIN THE APPLICABLE WARRANTY PERIOD.

IN NO EVENT SHALL WINCO BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES TO BUYER OR ANY THIRD PARTY, INCLUDING, WITHOUT LIMITATION, LOSS OF PROPERTY, PERSONAL INJURY, LOSS OF BUSINESS OR PROFITS OR OTHER ECONOMIC LOSSES, OR STATUTORY OR EXEMPLARY DAMAGES, WHETHER IN NEGLIGENCE, WARRANTY, STRICT LIABILITY, OR OTHERWISE.

This warranty is given only to the first purchaser from a retail dealer. No warranty is given to subsequent transferees.

Warranty does not cover product failures caused by: failure to maintain, neglect, abuse, damage due to excess water, fire, normal wear, improper set up and use. Periodic maintenance is not covered.

This warranty is not in force until such time as a properly completed and digitally signed Installation/Warranty Registration has been received by WINCO within 30 days from the date of installation.

WARRANTY SERVICE

To initiate warranty service contact: support@wincous.com
or call: 973-295-3899

DO NOT send unit to WINCO without first contacting our customer service department.

REGISTER ONLINE AT:

<http://support.wincous.com>

Proof of purchase is required to extend warranty more than 1 year from date of shipment from the factory.


THE FOREGOING WARRANTY PROVISIONS ARE A COMPLETE AND EXCLUSIVE STATEMENT BETWEEN THE BUYER AND SELLER. WINCO NEITHER ASSUMES NOR AUTHORIZES ANY PERSONS TO ASSUME FOR IT ANY OTHER OBLIGATION OR LIABILITY IN CONNECTION WITH SAID EQUIPMENT.

Examples of items not covered under warranty, but not limited to just these items:

1. Acts of God, fire, water damage, burglary, accident, theft.
2. Freight damage.
3. Improper installation or alteration of equipment.
4. Use of generic or after market parts.
5. Repairs made by anyone other than a WINCO designated service provider.
6. Lubrication.
7. Expendable wear parts, adjustable feet, blown fuses, lamps, etc.
8. Cleaning of equipment.
9. Misuse or abuse.

WARRANTY REGISTRATION

SCAN THE QR CODE WITH YOUR MOBILE DEVICE



or go to

<http://support.wincous.com>

TO FILL OUT AND SUBMIT YOUR WARRANTY REGISTRATION.

Please keep this manual in a safe place for future use!